
Honeywell

186 Bottle Wine Cooler
User Manual

Read and save these instructions before use



H186WCS

CONTENTS

1 Safety Warnings

1.1 Warning 1-2

1.2 Meaning of safety warning symbols 3

1.3 Electricity related warnings 3

1.4 Related warnings for use 4

1.5 Warnings related to placing items 4

1.6 Warnings for energy 5

1.7 Warnings related to disposal 5

2 Installation Instructions

2.1 Before using your wine chiller 6

2.2 Installation of your wine chiller 6

2.3 Electrical Connection 7

2.4 Temperature 7

2.5 Shelves 7

3 Operation Istructions

3.1 Cleaning 10

3.2 Power Failure 10

3.3 Moving your wine chiller 10

3.4 Energy Saving Tips 10

3.5 Recycling and disposal 11

3.6 Charcoal Filtration System 11

3.7 Names of Components 12

4 Troubleshooting 13

1 SAFETY WARNINGS

1.1 Warning



WARNING: risk of fire / flammable materials

Plug into a grounded 3-prong outlet, do not remove grounding prong, do not use an adapter, and do not use an extension cord.

Replace all panels before operating.

It is recommended that a separate circuit, serving only your appliance be provided. Use receptacles that cannot be turned off by a switch or pull chain.

Never clean appliance parts with flammable fluids. These fumes can create a fire hazard or explosion. And do not store or use gasoline or other flammable vapour and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.

Before proceeding with cleaning and maintenance operations, make sure the power line of the unit is disconnected.

Do not connect or disconnect the electric plug when your hands are wet.

Unplug the appliance or disconnect power before cleaning or servicing. Failure to do so can result in electrical shock or death.

Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this material. All other servicing should be referred to a qualified technician.

WARNING: Use two or more people to move and install appliance. Failure to do so can result in back or other injury.

WARNING: To ensure proper ventilation for your appliance, the front of the unit must be completely unobstructed. Choose a well-ventilated area with temperatures above 16°C (60°F) and below 32°C (90°F). This unit must be installed in an area protected from the element, such as wind, rain, water spray or drips.

WARNING: The appliance should not be located next to ovens, grills or other sources of high heat.

WARNING: The appliance must be installed with all electrical, water and drain connections in accordance with state and local codes. A standard electrical supply (115V/60Hz), properly grounded in accordance with the National Electrical Code and local codes and ordinances is required.

WARNING: Do not kink or pinch the power supply cord of appliance.

WARNING: The fuse (or circuit breaker) size should be 13 amperes.

WARNING: It is important for the appliance to be leveled in order to work properly. You may need to make several adjustments to level it.

WARNING: Do not use solvent-based cleaning agents of abrasives on the interior. These cleaners may damage or discolour the interior.

WARNING: Do not use this apparatus for other than its intended purpose.

DANGER – Risk of fire or explosion. Flammable refrigerant used.

DO NOT use mechanical devices to defrost refrigerator. DO NOT puncture refrigerant tubing.

DANGER – Risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. DO NOT puncture refrigerant tubing.

CAUTION – Risk of fire or explosion. Flammable refrigerant used. Consult repair manual / owner's guide before attempting to service this product. All safety precautions must be followed.

CAUTION – Risk of fire or explosion. Dispose of property in accordance with federal or local regulations. Flammable refrigerant used.

CAUTION – Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully. Flammable refrigerant used.

CAUTION – To prevent a child from being entrapped, keep out of reach of children and not in the vicinity of the cooler.

Read all instructions before using the wine chiller.

Before you throw away your old wine chiller, take off the door but leave the shelves in place so that children may not easily climb inside.

Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.

Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.

1.2 Meaning of Safety Warning Symbols

 Prohibition Symbols	The symbols indicate prohibited matters, and those behaviors are forbidden. Non-compliance with the instructions may result in product damages or endanger the personal safety of users.
 Warning Symbols	The symbols indicate matters that must be followed, and those behaviors must be strictly executed in line with the operation requirements. Non-compliance with the instructions may result in product damages or endanger the personal safety of users.
 Note Symbols	The symbols indicate matters to pay attention to, and these behaviors shall be specially noted. Due precautions are needed or minor or moderate injuries or damages of the product will be caused.

This manual contains important safety information that should be observed by users.

1.3 Electricity Related Warnings

- Do not pull the power cord when pulling the power plug of the cooler. Please firmly grasp the plug and pull it out from the socket directly.



- Do not damage the power cord under any condition, do not use when the power cord is damaged or the plug is worn.
- Worn or damaged power cord should be replaced in manufacturer-authorized maintenance stations.



- The power plug should be firmly contacted with the socket or else a fire might be caused. Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.



- Please turn off the valve of the leaking gas and then open the doors and windows in case of leakage of gas and other flammable gases. Do not unplug the cooler and other electrical appliances considering that spark may cause a fire.



- To ensure safety, it is not recommended that to place regulators, rice cookers, microwave ovens and other appliances on the top of the beverage cooler, those recommended by the manufacturer are not included. Do not use electrical appliances in the food pantry.

1.4 Related Warnings for Use

- Do not arbitrarily disassemble or reconstruct the cooler, nor damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist.
- Damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.

- The gaps between cooler door and cooler body are small, be noted not to put your hand in these areas to prevent from squeezing the finger. Please be gentle when closing or opening the cooler door to avoid falling articles.

- Do not give package and other components to children to play. The bending board and plastic film may cause suffocation. Do not allow children to enter or climb the cooler to prevent that children are sealed in the cooler or children are injured by the falling cooler.
- Do not spray or wash the cooler; do not put the cooler in moist places easy to be splashed with water so as not to affect the electrical insulation properties of the cooler.
- Do not use cooler body, cooler door, etc. as pedal or support.

- Do not place heavy objects on the top of the cooler considering that objects may fall when opening or closing the door, and accidental injuries might be caused.
- Please pull out the plug in case of power failure or cleaning. Do not connect the cooler to power supply within five minutes to prevent damages to the compressor due to successive starts.

1.5 Warnings Related to Placing tems

- Do not put flammable, explosive, volatile and highly corrosive items in the cooler to prevent damages to the product or fire accidents.
- Do not place flammable items near the cooler to avoid fires

- This product is mainly used in the storage of wine. According to national standards, wine coolers shall not be used for other purposes, such as storage of blood, drugs or biological products.

1.6 Warnings for Energy

01 Cooler might not operate consistently when sited for an extended period of time below the cold end of the range of temperatures for which the cooler appliance is designed.

02 The need to not exceed the storage time(s) recommended by the wine manufacturers for any kind of beverage.

03 The precautions necessary to prevent an undue rise in the temperature of the wine while defrosting the cooler.

04 The fact that a rise in temperature of the wine during manual defrosting, maintenance or cleaning could shorten the storage life.

05 The necessity that, for doors or lids fitted with locks and keys, the keys be kept out of the reach of children and not in the vicinity of the cooler appliance, in order to prevent children from being locked inside.

1.7 Warnings Related to Disposal

Refrigerant and cyclopentane foaming material used for the cooler are flammable. Therefore, when the cooler is scrapped, it shall be kept away from any fire source and be recovered by a recovering company with corresponding qualification other than be disposed of by combustion, so as to prevent damage to the environment or any other harm.

When the cooler is scrapped, disassemble the doors, and remove gasket of door and shelves; put the doors and shelves in a proper place, so as to prevent trapping of any child.



Correct Disposal of this product:
This marking indicates that this product should not be disposed with other wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

2 OPERATING YOUR WINE COOLER

2.1 Before using your wine chiller

Remove the exterior and interior packing.

Check to be sure you have all of the following parts:

- 14 Beech Shelves

- 2 Keys

- Stainless Steel Handle

- Instruction Manual

- 2 Extra Screws for Installing Handle

Before connecting the Wine cooler to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.

Clean the interior surface with lukewarm water using a soft cloth.

2.2 Installation

This wine cooler is designed for free standing or built-in (fully recessed) installation.

Place your wine cooler on a solid and level floor that is strong enough to support it when it is fully loaded. This will ensure a vibration-free and noise-free operation. Adjust the leveling legs in and out to stabilize the cooler horizontally. If the legs are not properly adjusted, the cooler may be unstable and result in excess noise or vibration.

Locate the wine cooler away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extremely cold ambient temperatures may also cause the cooler not to perform properly.

It is not advisable to install this cooler in moist areas or directly adjacent to a kitchen sink, as moisture could cause premature corrosion to the components of your new cooler.

It is recommended you install the wine cooler in a place with temperatures above 60°F (15°C) and below 90°F (32°C), and humidity is under 60%. If the ambient temperature is above or below recommended temperatures, the performance of the cooler may be affected. Placing your cooler in extremely cold or hot conditions may cause interior temperatures to fluctuate, and the temperature range of 5°C-18°C (40°F-65°F) may not be reached.

Connect the wine cooler to an exclusive, properly grounded, standard electrical supply (115 V AC only, 60 Hz), in accordance with the National Electrical Code and local codes and ordinances. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorized products service center.

2.2 Installation

WARNING:

The wine cooler should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the wine cooler. This provides the best performance and also prevents overloading house wiring circuits that could cause a fire hazard from overheated.

Do not under any circumstances cut or remove the third ground prong from the power cord supplied.

Do not use an extension cord or adapter plug. However, if you must use an extension cord, it is absolutely necessary that it be a UL-listed, 3-wire grounding type wine cooler extension cord having a grounding type plug and outlet and that the electrical rating of the cord is 10 amperes (minimum) and 120 volts.

Do not use a cord that shows cracks or abrasion damage along its length or at either end.

If the wine cooler is going to be used in an area that is prone to power surges/ outages, it is suggested that you use a power surge protector. The surge protector that you select must have a surge block high enough to protect the wine cooler it is connected to. Damages due to power surges are not considered a manufacturer covered defect and will void your product warranty.


2.3 Installing the Handle


1) Pull away the door gasket in the area where the handle is to be installed, as Illustration #1. The gasket is easily removed by hand, no tools are necessary.

2) Align the handle with the pre-installed screws on the door frame. Tighten the screws with a screwdriver until the handles secure tightly against the door frame, as Illustration #2. (Do NOT over tighten as this will cause damage to the handle assembly).

3) Replace the door gasket to its original position.

Note: This wine cooler includes stainless steel handles that are not required to operate this wine cooler. If you choose not to use the handle supplied, simply follow step 1 to access the pre-installed screws and remove them and then place 2 decorative plugs (NOT included) into the two holes separately. Continue on to step 3 to replace the door gasket to its original position.





1. Gasket
2. Screw
3. Screwdriver
4. Handle

2.4 Temperature

It is recommended you install the wine cooler in a place where the ambient temperature is between

19ºC-24ºC (66ºF-75ºF), and humidity is under 60%. If the ambient temperature is above or below

recommended temperatures, the performance of the unit may be affected. For example, placing your unit in extreme cold or hot conditions may cause interior temperatures to fluctuate.

Recommended temperature settings

Wine conservation: 12ºC-14ºC (53ºF-57ºF)


Rose and sparkling wines: 5ºC-8ºC (41ºF-46ºF)

Dry/white wines: 9ºC-12ºC (48ºF-53ºF)

Red wines: 14ºC-18ºC (59ºF-65ºF)

*Temperature ºC may varies between ≤ ± 2 ºC

2.5 Control Panel



Press ⓘ once to turn the interior light ON or OFF.

Press ⌃ to increase or press ⌃ to decrease the temperature in 1 degree increments between. Upper zone 5ºC-13ºC(40-55), Lower zone13ºC-18ºC (55-65).

Press ⓘ to begin adjusting the temperature for upper or lower zone

Press ⏻ once to turn ON the cooler. Press and hold about 3 seconds to turn OFF the cooler.

ºF/ºC Toggles the temperature display between Celsius and Fahrenheit.

2.6 Storage

This wine cooler is designed to store standard Bordeaux 750 ml wine bottles. Many bottles differ in size and dimensions. As such, the actual number of bottles you may be able to store may vary. Storing large and/or oddly shaped bottles (including champagne and sparkling wine bottles) will decrease the capacity of your wine cooler.

2.7 Door Lock

This cooler can be secured with a lock and key. The keys are located inside the plastic bag that contains the Instruction Manual. Insert the key into the lock and turn it clockwise to lock the door, making sure the metal pin is engaged completely. To unlock the door, do the reverse. Remove the key and put it in a secure location.

2.8 Beech Shelves

This wine cooler is equipped with a sliding rail assembly and you can move the wooden shelves out and in smoothly.

The slide-out shelves allow bottles of wine to be viewed and removed more easily. Any of the shelves can be removed to store larger bottles.

To prevent damaging the door gasket, make sure to have the door all the way opened when pulling shelves out of the rail compartment. For easy access to the bottles, you may need to pull the shelves approximately 1/2 out of the rail compartment.

2 INSTALLATION INSTRUCTIONS


2.5 Shelves

To Remove a Sliding Shelf

1. Remove all bottles from the shelf.

2. Pull the shelf out as far as it will go.

3. Adjust the lever on each side of the shelf, as shown below (UP on the left, DOWN on the right) and at the same time, pull the shelf out completely.



3 CARE AND MAINTENANCE

3.1 Cleaning your wine cooler

IMPORTANT: Always unplug the cooler before cleaning or performing maintenance. Never use harsh cleansers or scouring pads to clean any part of the cooler.

Turn off the power, unplug the appliance, and remove all items including shelves

Wash the inside surfaces with a warm water and soft cloth

Wash the shelves with a mild detergent solution

Wring excess water out of the sponge or cloth when cleaning area of the controls, or any electrical parts

Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth. Do not use steel wool or steel brush on the stainless steel. These will contaminate the stainless steel with steel particles and rusting may occur.

3.2 Power Failure

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened. If the power is going to be off for a longer period of time, you need to take the proper steps to protect your contents.

3.3 Moving your wine cooler

-Remove all items (bottles)

-Tape down securely all loose items (shelves) inside your appliance.

-Turn the adjustable leg up to the base to avoid damage.

-Tape the door shut. Be sure the appliance stays secure in the upright position during transportation. If you absolutely need to transport the cooler horizontally, transport the cooler on its back (door on top). Also protect outside of appliance with a blanket, or similar item.

3.4 Energy saving tips

-The wine cooler should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.

3 CARE AND MAINTENANCE

3.1 Cleaning your wine cooler

IMPORTANT: Always unplug the cooler before cleaning or performing maintenance. Never use harsh cleansers or scouring pads to clean any part of the cooler.

Turn off the power, unplug the appliance, and remove all items including shelves

Wash the inside surfaces with a warm water and soft cloth

Wash the shelves with a mild detergent solution

Wring excess water out of the sponge or cloth when cleaning area of the controls, or any electrical parts

Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth. Do not use steel wool or steel brush on the stainless steel. These will contaminate the stainless steel with steel particles and rusting may occur.

3.2 Power Failure

Most power failures are corrected within a few hours and should not affect the temperature of your wine cooler. If the power is off for an extended period of time, proper steps should be taken to protect your contents.

3.2 Vacation Time

Leave the wine cooler operating during vacations of less than three weeks. For periods longer than this, turn the wine cooler off and leave the door slightly ajar to prevent odor from building inside the wine cooler.

3.3 Moving your wine cooler

-Remove all items (bottles)

-Tape down securely all loose items (shelves) inside your appliance.

-Turn the adjustable leg up to the base to avoid damage.

-Tape the door shut. Be sure the appliance stays secure in the upright position during transportation. If you absolutely need to transport the cooler horizontally, transport the cooler on its back (door on top). Also protect outside of appliance with a blanket, or similar item.

3.4 Energy saving tips

-The wine cooler should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.

3 CARE AND MAINTENANCE


3.5 Charcoal filtration system

Your wine is a living object that breathes through the cork of its bottle. In order to preserve the quality and taste of your fine wines, they must be stored at the ideal temperature and ambient conditions. Your cooler is equipped with an active charcoal filtration system to ensure air purity, cooling efficiency, and to maintain an odor free cabinet for the storage of your fine wines. The filter assembly is located at the rear panel inside your cooler. Keep in mind, that this filter must be changed every 12 months.

Remove the bottles of wine stored on the two (2) shelves in front of the filter.	Turn Left to remove filter.
Remove the shelves and set aside to be replaced once you have changed the filter	
Hold the filter and turn it at 45 degrees in the counter-clockwise direction and then pull it out.	
Remove the existing filter and replace with a new one.	
Put the new filter into the hole and then turn the filter at 45 degrees in clockwise direction.	

3 OPERATION INSTRUCTIONS

3.7 Names of Components



4 TROUBLESHOOTING

The following simple issues can be handled by the user. Please call the after-sale service department if the issues are not settled.

Inoperation	Check whether the cooler is connected to power Check if there is low voltage. Check if weather control knob is in the work area. Check whether there is a power failure or partial circuits have tripped.	Plug the unit. Press to turn on the unit. Check the breaker and/or fuses.
Chiller Is Not Cold Enough.	External environment may require a higher setting. The door is opened too often. The door is not closed completely. The door gasket does not seal properly.	Long operation of the cooler is normal in summer when the ambient temperature is high. Do not put too many beverages in the cooler at one time. The doors are opened too frequently.
The compressor turns on and off frequently.	The room temperature is hotter than normal. A large amount of contents has been added to the chiller. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly.	Close the door properly. Check the door gasket.
The fans turn on and off frequently.	In order to circulate the air and maintain the set temperature inside the cabinet the fans must cycle on and off even when the compressor is off. The fans will cycle ON and OFF while the compressor is off approximately every 10 seconds, this is called “Semi-speed status”. This cycle is normal and meant both to circulate the air as well as ensure the continued operational status of the fans. If the fan stops completely and does not complete this cycle the fan is non-operational.	
The light does not work.	Not plugged in. The circuit breaker tripped or a blown fuse. The light button is “OFF”.	Plug the unit. Check the breaker and/or fuses.
Vibrations.	The chiller is not leveled The bottles are vibrating. There is an object under the chiller.	Check to assure that the chiller is level. Make sure the bottles don’t touch each other. Remove the object.
The chiller seems to make too much noise.	The chiller is not level.	Level the chiller. The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your chiller. Contraction and expansion of the inside walls may cause popping and crackling noises.
The door will not close properly.	The chiller is not level. The door was reversed and not properly installed. The gasket is dirty. The shelves are out of position.	Check to assure that the chiller is level. Make sure the bottles don’t touch each other. Remove the object.
Error Code E1, E2, E3, E4	Temperature sensor disconnect. Temperature sensor failure. Evaporator temperature sensor disconnected.	Contact us for a service call.

If you want to return or replace the product, please contact the store where it was purchased (remember to bring the purchase invoice). If your product needs repair, please contact us via email or phone.

BHRS Group, LLC

585 Prospect St.
Lakewood, NJ 08701

Customer Service Tel: 1-888-604-0295
Customer Service Email: support@honeywellcoolingappliances.com
Website: honeywellcoolingappliances.com

©2024 BHRS Group, LLC. All Rights Reserved.

The Honeywell Trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product. This product is manufactured by BHRS Group, LLC.

MADE IN CHINA

Honeywell