Honeywell

STANDBY GENERATORS

11 kW / 15 kW / 20 kW AIR-COOLED GENERATOR SETS

Standby Power Rating

Model 006442-0 (Aluminum - Dark Gray) - 11 kW 60Hz Model 006261-0 (Aluminum - Dark Gray) - 15 kW 60Hz Model 006262-0 (Aluminum - Dark Gray) - 20 kW 60Hz

INCLUDES

- PrecisionPower[™] Electrical Technology
- Two Line LCD Multi-lingual Digital Controller (English/Spanish/French/Portuguese)
- Electronic Governor
- External Main Circuit Breaker, System Status
 & Maintenance Interval LED Indicators
- Flexible Fuel Line Connector
- · GFCI Duplex Outlet
- WhisperCheck[™] Exercise (11, 15 & 20kW)



- Includes Mobile Link™ Monitoring System
- · Composite Mounting Pad
- Aluminum Enclosure
- Base Fascia
- · Natural Gas or LP Gas Operation
- 5 Year Comprehensive Warranty
- UL 2200 Listed



USA ENGINEERED & DUILT

FEATURES

• INNOVATIVE DESIGN & PROTOTYPE TESTING are key

components of our success in "IMPROVING POWER BY DESIGN." But it doesn't stop there. Total commitment to component testing, reliability testing, environmental testing, destruction and life testing, plus testing to applicable CSA, NEMA, EGSA, and other standards, allows you to choose Honeywell generators with the confidence that these systems will provide superior performance.

O TEST CRITERIA

- PROTOTYPE TESTED
- SYSTEM TORSIONAL TESTED
- NEMA MG1-22 EVALUATION
- MOTOR STARTING ABILITY

O PrecisionPower™ ELECTRICAL

TECHNOLOGY Superior harmonics and sine wave form produce less than 5% Total Harmonic Distortion for utility quality power. This allows confident operation of sensitive electronic equipment and micro-chip based appliances, such as variable speed HVAC.

SOLID-STATE, FREQUENCY COMPENSATED VOLTAGE REGULATION This state-of-the-art power

maximizing regulation system is standard on all Honeywell models. It provides optimized FAST RESPONSE to changing load conditions and MAXIMUM MOTOR STARTING CAPABILITY by electronically torque-matching the surge loads to the engine. Digital voltage regulation at +/- 1%.

- SINGLE SOURCE SERVICE RESPONSE from our extensive dealer network provides parts and service knowhow for the entire unit, from the engine to the smallest electronic component.
- Honeywell[®] TRANSFER SWITCHES The Honeywell[®] generator line offers its own transfer systems and controls for total system compatibility.
- Mobile Link Cellular Monitoring System - Mobile Link is the new cellular remote monitoring system that lets you check your generator's status even when you are away using your computer, tablet or smart phone. With Mobile Link, you will always know exactly what your generator is doing when you are on the go.

11 kW / 15 kW / 20 kW AIR-COOLED GENERATOR SETS

ENGINE

Maximizes engine "breathing" for increased fuel efficiency. Plateau honed cylinder walls and plasma moly rings help the engine run cooler, reducing oil consumption resulting in longer engine life.
Rigid construction and added durability provide long engine life.
These features combine to assure smooth, quick starting every time.
Pressurized lubrication to all vital bearings means better performance, less maintenance and longer engine life. Now featuring up to a 2 year/200 hour oil change interval.
Superior shutdown protection prevents catastrophic engine damage due to low oil.
Prevents damage due to overheating.

GENERATOR

Revolving field	Allows for smaller, light weight unit that operates 25% more efficiently than a revolving armature generator.
Skewed stator	Produces a smooth output waveform for compatibility with electronic equipment.
Displaced phase excitation	Maximizes motor starting capability.
Automatic voltage regulation	Regulates the output voltage to $\pm 1\%$ prevents damaging voltage spikes.
• UL 2200 listed	For your safety.

TRANSFER SWITCH

Sold separately

CONTROLS	
Auto/Manual/Off illuminated buttons	Selects the operating mode and provides easy, at-a-glance status indication in any condition.
Sealed, raised buttons	Smooth, weather-resistant user interface for programming and operations.
Utility voltage sensing	Constantly monitors utility voltage, setpoints 60% dropout, 80% pick-up, of standard voltage.
Generator voltage sensing	Constantly monitors generator voltage to ensure the cleanest power delivered to the home.
Utility interrupt delay	Prevents nuisance start-ups of the engine, adjustable 2-1500 seconds from the factory default setting of 10 seconds by a qualified dealer.
Engine warm-up	Ensures engine is ready to assume the load, setpoint approximately 5 seconds.
Engine cool-down	Allows engine to cool prior to shutdown, setpoint approximately 1 minute.
Programmable seven day exerciser	Operates engine to prevent oil seal drying and damage between power outages by running the generator for 12 minutes every week.
Smart battery charger	Delivers charge to the battery only when needed at varying rates depending on outdoor air temperature.
Main line circuit breaker	Protects generator from overload.
Electronic governor	Maintains constant 60 Hz frequency.

UNIT	
Aluminum weather protective enclosure	Provides protection against mother nature. Hinged key locking roof panel for security. Lift-out front for easy access to all routine maintenance items. Electrostatically applied textured epoxy paint for added durability.
Enclosed critical grade muffler	Quiet, critical grade muffler is mounted inside the unit to prevent injuries.
Small, compact, attractive	Makes for an easy, eye appealing installation.

INSTALLATION SYSTEM		
 1ft. (305mm) flexible fuel line connector Composite mounting pad	Easy installation.	

2


Number of Cylinders222Displacement530cc992cc999cc	GENERATOR	Model 006442-0 (11 kW)	Model 006261-0 (15 kW)	Model 006262-0 (20 kW)
Rater Maximum Continuous Power Capacity (NS) 10.000 Watts* 15.000 Watts* 12.000 Watts* Rater Miximum Continuous Land Current – 24.0V (LP/NS) 45.84.17. 62.59.62.5 83.37.5 Rater Miximum Continuous Land Current – 24.0V (LP/NS) 45.84.17. 62.59.62.5 83.37.5 Main Line Circuit Breaker 50 Amp 65 Amp 90 Amp Pinase 1 1 1 Number of Nator Poles 2 2 2 Bater M Resignemy 600Hz 60Hz 60Hz Power Factor 1.0 1.0 1.0 Dimensione LLX VK Hight Zmm 45.72.04.6 45.72.04.6 45.72.04.6 Sourd duptint rel(A) at 23.12.04.6 66 66 66 Sourd duptint rel(A) at 23.12.04.6 7 60 60 Sourd duptint rel(A) at 23.12.04.6 7 60 60 Sourd duptint rel(A) at 23.12.07.6 7 60 60 Sourd duptint rel(A) at 23.12.07.6 7 60 60 Sourd duptint rel(A) at 23.12.07.6 7 60 60 <t< td=""><td>Rated Maximum Continuous Power Capacity (LP)</td><td>11.000 Watts*</td><td>15.000 Watts*</td><td>20.000 Watts*</td></t<>	Rated Maximum Continuous Power Capacity (LP)	11.000 Watts*	15.000 Watts*	20.000 Watts*
Batel Voltagie 240 240 240 240 Batel Marinne Childroninous Load Current – 240V (LP/NG) 4.58,441.7 62,562.5 53,375 Total Harmonic Distortion Less than 5%		,	,	,
Rate Maximum Continuous Dad Current – 240V (LP/NG) 43.841.7 62.5.42.3 83.375 Dirab Harmonic Distorion Lass than 5%		,	,	
Total Harmonic Distortion Less than 5% Less than 5% <thless 5%<="" th="" than=""> L</thless>	•	45.8/41.7	62.5/62.5	
Main Loc Crunt Bracker 50 Amp 60 Amp 90 Amp Pilase 1 1 Number of Noor Poles 2 2 2 Brack AD Frequeny 0.0042 80 Mz 60 Mz Power Factor 1.0 1.0 1.0 0.0 Brack AD Frequenty 63 Amp 65 X 247128 K 588 X 72 45 X 240 X 16 K 588 X 72 Demensions (L, Wx W Ih) m/mm 63 X 260 X 24 X 15 K 588 X 72 66 66 Sound dupt in 68(A) at 23 R (7m) with generator in WhisperCheck* 67 60 66 Sound dupt in 68(A) at 23 R (7m) with generator in WhisperCheck* 50 X 20 X	. , ,	,	,	
Place 1 1 1 1 Number of NoroPoles 2 2 2 Bated AC Frequency 600/z 604/z 604/z Power Factur 1.0 1.0 1.0 Battery Requirement (not included) Groug 261, 12 Volts and 55 CM Minimum 45 1/204.6 Dimensions (L, XW xH) in mm 373/169.2 451/204.6 Sound output in GR(A) at 23 ft. (7m) with generator in WhisperCheck** 63 66 66 Sound output in GR(A) at 23 ft. (7m) with generator in WhisperCheck** 57 60 60 EVGINE EVGINE 2				
Number of Folior Polies 2 2 2 Bath AG Forguency 601/e 601/e 601/e Power Factor 1.0 1.0 1.0 Demensions (L, W, KH) In/Imm Giorag EBR (2V) and 525 (CA Minimum 437/198.2 437/198.2 451/204.6 Demensions (L, W, KH) In/Imm Giorag ZBR (2V) and s038 x732 500 60 60 Sound output in dB(A) at 23 ft. (7m) with generator operating at normal Gio secretise mode 63 66 66 Sound output in dB(A) at 23 ft. (7m) with generator in Whisper/Check ^m 57 60 60 67 Sound output in dB(A) at 23 ft. (7m) with generator in Whisper/Check ^m 57 60 60 67 View Speed exercise mode 2				
Rate AC Frequency Boh/z Boh/z Boh/z Power Factor 1.0 1.0 1.0 1.0 Battery Requirement (not included) Group 26R, 12 Voits and 52 CoA Minimum 43 x 25 x 201/12 x 633 x 713 Demensions (L, K W X H) m./mm 44 x 25 x 201/12 x 633 x 713 451/204.6 Demensions (L, K W X H) m./mm 63 66 66 Sourd output in dB(A) at 23 tt. (7m) with generator in Whisper/Deck** 57 60 60 With speed Earnies mode 2 2 2 2 Displacement 2				
Power Factor 1.0 1.0 1.0 Bettery Flequineent dott include(1) Group 268, 12, Volls and 526 CGA Minum 451/204.6 Dimensions (1, XLW H) in /rm 48 z 5 x 29/128 x 653 r 732 66 66 Sound output in 68(A) at 23 ft. (7m) with generator operating at normal load 63 66 66 Sound output in 68(A) at 23 ft. (7m) with generator in Whisper/Check** 57 60 60 ENGINE ENGINE ENERAC OHVI V-TWIN ENERAC OHVI V-TWIN ENERAC OHVI V-TWIN With Providers 2				
Battery Requirement, foot Included) Group 22R, 12 Voits and 325 CoA Minimum University (Law XH xH) in runm 48 x 25 x 29/1218 x 638 x 732 Sound a totage In Ide (A) at 23 II. (7m) with generator in WhisperCheck** 63 66 66 Sound a totage In Ide (A) at 23 II. (7m) with generator in WhisperCheck** 57 60 60 Exclision 2				
Unit Weight (Pounds:Kins) 373/169.2 439/198.2 451/204.6 Dimensions (L, VK H) In ,mm 48 x 25 x 29/1218 x 638 x 73 56 66 Sound output in dB(A) at 23 ft. (7m) with generator operating at normal load 63 66 66 Sound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck** 57 60 60 EXCINC Sound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck** 57 60 60 EXCINC Sound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck** 530c0 92 generating in the interval interv				
Dimensions (L. XV xH) in Jumm (48 x 25 x 29/1218 x 638 x 732 Sound output in (B(A) at 23 t. (7m) with generator operating at normal load Sound output in (B(A) at 23 t. (7m) with generator in WhisperCheck ^m 77 60 60 ENGINE ENGINE ENGINE ENGINE ENGINE ENGINE Cylinder Bock 2 2 2 Displacement S030cc 992cc 999cc 999cc Cylinder Bock 4Luminum wCast foro Sleeve ALuminum wHI aND (Sleeve ALUMINUM WAI) for Sleeve ALUMINUM WHI aND (Sleeve ALUMINUM WAI) for Sleeve ALUMINUM WHI aND (Sleeve ALUMINUM WAI) for Sleeve ALUMINUM WAI aND (Sleeve ALUMINUM WAI) for Sleeve ALUMINIM WAI) for Sleeve ALUMINI				
Sourd output in dB(A) at 21t. (7m) with generator operating at normal bad 63 66 66 Sourd output in dB(A) at 23. ft. (7m) with generator in WhisperCheck** 77 60 60 EVGINE EVENCE 2 <td> ,</td> <td>070/103.Z</td> <td>,</td> <td>431/204.0</td>	,	070/103.Z	,	431/204.0
Cound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck** 57 60 60 EVRINE EVRINE <td>Sound output in dB(A) at 23 ft. (7m) with generator operating at normal</td> <td>63</td> <td>· ·</td> <td>66</td>	Sound output in dB(A) at 23 ft. (7m) with generator operating at normal	63	· ·	66
Type of Engine GENERAC OHVI GENERAC OHVI V-TWIN GENERAC OHVI V-TWIN Number of Cylinders 2 2 2 2 Opiglacement 530cc 992cc 999cc 2 </td <td>Sound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck™</td> <td></td> <td></td> <td></td>	Sound output in dB(A) at 23 ft. (7m) with generator in WhisperCheck™			
Type of Engine GENERAC OHVI GENERAC OHVI V-TWIN GENERAC OHVI V-TWIN Number of Cylinders 2 2 2 2 Opiglacement 530cc 992cc 999cc 2 </td <td>FNGINF</td> <td></td> <td></td> <td></td>	FNGINF			
Number of Qyinders 2 2 Displacement 530cc 992cc 999cc Cyinder Block Aluminum wCast Iron Sleeve Aluminum MCast Iron Sleeve Aluminum Aluminum Iron Iron Iron Sleeve Aluminum Iron Iron Sleeve Aluminum MCast Iron Sleeve Aluminum MCast Iron Sleeve Aluminu I		GENERAC OHVI	GENERAC OHVI V-TWIN	GENERAC OHVI V-TWIN
Cylinder Block Aluminum w/Cast Iron Sleeve Aluminum w/	Number of Cylinders		2	2
Value ArrangementOverhead ValueOverhead ValueOverhead ValueIgnition SystemSolid-state w/MagnetoSolid-state w/MagnetoSolid-state w/MagnetoCompression Ratio9.5.19.5.19.5.1Starter12 Vdc12 Vdc12 VdcOil Capacity Including FilterApprox. 1.7 Qts./1.6LApprox. 1.9 Qts./1.8LApprox. 1.9 Qts./1.8LOperating RPM3.6003.6003.600Fuel Consumption12 Vdc12 Vdc12 VdcNatural Gasft ⁴ /hr (m ⁴ /hr)124 (3.51)135 (5.24)205 (5.8)1/2 Load124 (3.51)135 (5.52)296 (8.39)308 (8.72)Liquid Propaneft ⁴ /hr (ga/hr)1/2 Load195 (5.52)296 (8.39)308 (8.72)Liquid Propaneft ⁴ /hr (ga/hr)1/2 Load104 (2.8) (1.18) [4.45]66.4 (1.83) [6.91]75.6 (2.08) [7.87]Note: Fuel pipe must be sized for full Load.Required fuel pressure to generator fuel inlet - 3.5.7" water column (7-13mm mercury) for natural gas. 10.12" water colur(19-22mm mercury) for LP gas. For Blu content, multiply ft ⁴ /hr x 2500 (LP) or ft ⁴ /hr x 1000 (MG). For Megajoule content, multiply m ⁴ /hr x 93.15 (LP) or m ⁴ /hr x 37.26(NG).ControlStampter StandardProgrammable start delay between 2-1500 secondsStandardControl LD DisplayStandard Standard (programmable by dealer only)Uiting Valag Loss, Petern to Uiting AdjustableFrom 140-171/Vi190-216VFutur StandardStandardProgrammable start delay between 2-1500 secondsStandardUiting Valag				
Ignition SystemSolid-state w/MagnetoSolid-state w/MagnetoSolid-state w/MagnetoGovernor SystemElectronicElectronicElectronicCompression Rabo9.5.19.5.19.5.1Starter12 Vdc12 Vdc12 VdcOil Capacity Including FilterApprox. 1.7 Ots./1.6LApprox. 1.9 Ots./1.8LOperating RPM3.6003.6003.600Fuel Consumption1/2 Load124 (3.51)185 (5.24)205 (5.8)Vatural Gasft?/hr (m?/hr)1/2 Load124 (3.51)185 (5.24)205 (5.8)Liquid Propaneft?/hr (ga/hr)[Liters/hr]1/2 Load70 (1.92) (7.28)104 (2.46) (10.82)140 (3.35) (14.57)Note: Fuel pipe must be sized for fuel Loadrop (1.92) (7.28)104 (2.46) (10.82)rop (7.87)140 (3.35) (14.57)Note: Fuel pipe must be sized for fuel Load. Required fuel pressure to generator fuel linel + 3.57 vater column (7.713mm mercury) for ratural gas. 10.12" water columrop (7.92) (7.28)104 (2.46) (10.82)rop (7.87) (1.457)Note: Fuel pipe must be sized for fuel Load. Required fuel pressure to generator fuel linel + 3.57 vater column (7.713mm mercury) for ratural gas. 10.12" water columrop (7.92) (7.28)104 (2.46) (10.82)rop (7.87) (1.457)Note: Fuel pipe must be sized for fuel Load. Required fuel pressure to generator fuel linel + 3.57 vater column. (7.713mm mercury) for ratural gas. 10.12" water column (7.913mm mercu	Cylinder Block	Aluminum w/Cast Iron Sleeve	Aluminum w/Cast Iron Sleeve	Aluminum w/Cast Iron Sleeve
Governor System Electronic Electronic Electronic Compression Ratio 9.5:1 9.5:1 9.5:1 Starter 12 Vdc 12 Vdc 12 Vdc Oli Capacity Including Filter Approx. 1.7 Ots./1.6L Approx. 1.9 Ots./1.8L Approx. 1.9 Ots./1.8L Operating RPM 3.600 3.600 3.600 Natural Gas ft?/hr (m?/hr) 1.72 Load 124 (3.51) 185 (5.24) 205 (5.8) Fuel Consumption 1.72 Load 195 (5.52) 226 (8.38) 308 (8.72) Liquid Propane ft?/hr (m?/hr) 1.72 Load 192 (1.8) [4.45] 66.4 (1.83) (6.91] 75.6 (2.08) [7.87] Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7" water column (7-13mm mercury) for natural gas, 10.12" water colur 199 (2.552) 140 (2.86) [10.82] 140 (2.85) [14.57] Volt: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7" water column (7-13mm mercury) for natural gas, 10.12" water colur (IP3-22mm mercury) for LP gas. For Blu content, multiply ft?/hr x 2500 (LP) or ft?/hr x 1000 (NG). For Megaloule content, multiply m?/hr x 93.15 (LP) or m?/hr x 37.26 CONTE 2-Line Pl	Valve Arrangement	Overhead Valve	Overhead Valve	Overhead Valve
Compression Ratio 9.5:1 9.5:1 9.5:1 Starter 12 Vdc 12 Vdc 12 Vdc 12 Vdc Oli Capacity Including Filter Approx. 1.7 Otts/1.6L Approx. 1.9 Otts/1.8L Approx. 1.9 Otts/1.8L Operating RPM 3,600 3,600 3,600 3,600 Fuel Consumption 12 (2 add 124 (3.51) 185 (5.24) 205 (5.8) Fuil Load 124 (3.51) 185 (5.24) 205 (5.8) 308 (8.7) Liquid Propane ft*/hr (m?/hr) 1/LErs/hr) 1/LE (add 124 (3.51) 185 (5.24) 205 (5.8) Note: Fuel pipe must be steed for full load. Required fuel pressure to generator fuel intel -3.5-7* water column (7-103mm mecrury) for natural gas. 10-12* water colum (7-103mm mecrury) for natural gas. 10-12* water col	Ignition System	Solid-state w/Magneto	Solid-state w/Magneto	Solid-state w/Magneto
Starter 12 Vdc 12 Vdc 12 Vdc 12 Vdc Oil Capacity Including Filter Approx. 1.7 (tst/1.6L Approx. 1.9 (tst/1.8L Approx. 1.9 (tst/1.8L Operating RPM 3,600 3,600 3,600 Natural Gas ft/hr (m?/hr) 12 Load 124 (3,51) 185 (5.24) 205 (5.8) Liquid Propane ft?/hr (m?/hr) 12 Load 124 (3,51) 185 (5.24) 205 (5.8) Liquid Propane ft?/hr (m?/hr) 12 Load 70 (1.92) (7.28) 104 (2.86) [10.82] 140 (3.85) [14.57] Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7" water colurn (7-13mm mercury) for natural gas, 10-12" water colur (19-22mm mercury) for LP gas. For Blu content, multiply ft/hr x 2500 (LP) or ft/hr x 1000 (NG). For Megajoule content, multiply m?/hr x 93.15 (LP) or m?/hr x 37.26 (NG). CONTROLS Control and Start with starter control, unit stays on. If utility fails, transfer to load takes place. Off Stops unit. Power is removed. Control and charger still operate. Ready to Run/Waintenance Messages Standard Programmable by between 2-1500 seconds Standard (Drogrammable by delar only) Utility Voltage Loss/Return to Utility Adjustable From 140-171V/190-216V Future Set Capable Exerciser/Serciser Set Error Warning Standard (Drogrammable by delar only) <td< td=""><td>Governor System</td><td>Electronic</td><td>Electronic</td><td>Electronic</td></td<>	Governor System	Electronic	Electronic	Electronic
Oil Capacity Including Filter Approx. 1.9 Qts/1.8L Approx. 1.9 Qts/1.8L Approx. 1.9 Qts/1.8L Approx. 1.9 Qts/1.8L Operating RPM 3,600 3,600 3,600 Natural Gas ft?/hr (m?/hr) 125 205 (5.8) I/2 Load 124 (3.51) 135 (5.24) 205 (5.8) I/2 Load 124 (3.51) 145 (5.24) 205 (5.8) I/2 Load 124 (3.51) 145 (5.4) 205 (6.8) (7.8) Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fue linel - 3.5-7" water column (7-13mm mercury) for natural gas. 10-12" water colum (19-22mm mercury) for 14" gas. For Blu content, multiply ff?/hr x x2500 (LP) or ff?/hr x x1000 (NG). For Megajoule content, multiply m?/hr x 93.15 (LP) or m?/hr x 37.26 Mode Buttons: Auto Auto </td <td>Compression Ratio</td> <td>9.5:1</td> <td>9.5:1</td> <td>9.5:1</td>	Compression Ratio	9.5:1	9.5:1	9.5:1
Operating RPM 3,600 3,600 3,600 Fuel Consumption Natural Gas ft?/hr (m³/hr) Natural Gas ft?/hr (m³/hr) 1/2 Load 124 (3.51) 185 (5.24) 205 (5.8) Liquid Propane ft?/hr (ga/hr) [Liters/hr] 1/2 Load 124 (3.51) 185 (5.22) 296 (6.38) 308 (6.72) Liquid Propane ft?/hr (ga/hr) [Liters/hr] 1/2 Load 70 (1.92) [7.28] 104 (2.86) [10.82] 140 (3.85) [14.57] Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7 water column (7-13mm mercury) for natural gas. 10-12" water colum 104 (2.86) [10.82] 140 (3.85) [14.57] Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7" water column (7-13mm mercury) for natural gas. 10-12" water colum 104 (2.86) [10.82] 140 (3.85) [14.57] Note: Fuel pipe must be sized for full load. Required fuel pressure to generator fuel inlet -3.5-7" water column (7-13mm mercury) for natural gas. 10-12" water colum 104 (2.86) [10.82] 140 (3.85) [14.57] Note: Fuel pipe must be sized for full load. Required fuel piter x 2500 (LP) or ft?/hr x 1000 (NG). For Megiaoule content, multiply m?/hr x 37.26 (NG). CONTROLS Simple user interface for ease of operation. Mode Buttons: Automa	Starter	12 Vdc	12 Vdc	12 Vdc
Fuel Consumption Natural Gas If the (m3/hr) 1/2 Load Fuel Load 124 (3.51) 195 (5.52) 185 (5.24) 296 (8.38) 205 (5.8) 308 (8.72) Liquid Propane It*/hr (gal/hr) [Liters/hr] 1/2 Load 124 (3.51) 195 (5.52) 185 (6.24) 296 (8.38) 205 (5.8) 308 (8.72) Note: Fuel pige must be sized for full load. Required fuel pressure to generator fuel inlet - 3.5-7" water column (7-13mm mercury) for natural gas, 10-12" water colum (NG). CONTROLS Sum mercury) for LP gas. For Blu content, multiply ft*/hr x 2500 (LP) or ft*/hr x 1000 (NG). For Megajoule content, multiply m3/hr x 93.15 (LP) or m3/hr x 37.26 (NG). CONTROLS Sumal Standard Manual Start with starter control, unit stays on. If utility fails, transfer to load takes place. Marual Start with starter control, unit stays on. If utility fails, transfer to load takes place. Off Standard Programmable start delay between 2-1500 seconds Standard Future Set Capable Exercise Set Error Warning Standard Run/Alarn/Maintenance Logs S0 Events Each Engine Run Hours Indication Standard Run/Alarn/Maintenance Logs S0 Events Each Engine Run Hours Indication Standard Run/Alarn/Maintenance Log	Oil Capacity Including Filter	Approx. 1.7 Qts./1.6L	Approx. 1.9 Qts./1.8L	Approx. 1.9 Qts./1.8L
Natural Gasft*/hr (m*/hr) 1/2 Load124 (3.51)185 (5.24)205 (5.8) 308 (8.72)Liquid Propaneft*/hr (ga/hr) [Liters/hr] 1/2 Load195 (5.52)296 (8.38)308 (8.72)Liquid Propaneft*/hr (ga/hr) [Liters/hr] 1/2 Load42.8 (1.18) [4.45]66.4 (1.83) [6.91]75.6 (2.08) [7.87] 104 (2.86) [10.22]Note:Fuel pipe must be sized for ful load. Required fuel pressure to generator fuel initel - 3.5-7" water column (7-13mm mercury) for natural gas, 10-12" water	Operating RPM	3,600	3,600	3,600
High and the second	Natural Gas ft ³ /hr (m ³ /hr) 1/2 Load Full Load			
(19-22mm mercury) for LP gas. For Btu content, multiply ft³/hr x 2500 (LP) or ft³/hr x 1000 (NG). For Megajoule content, multiply m³/hr x 93.15 (LP) or m³/hr x 37.26 (NG). CONTROLS 2-Line Plain Text Multi-Lingual LCD Display Mode Buttons: Auto Manual Start with starter control, unit stays on. If utility fails, transfer to load takes place. Off Start with starter control, unit stays on. If utility fails, transfer to load takes place. Off Storps unit. Power is removed. Control and charger still operate. Ready to Run/Maintenance Messages Standard Engine Run Hours Indication Standard Programmable start delay between 2-1500 seconds Standard (programmable by dealer only) Utility Voltage Loss/Return to Utility Adjustable From 140-171V/190-216V Future Set Capable Exerciser/Exercise Set Error Warning Standard Run/Alarm/Maintenance Logs 50 Events Each Engine Start Sequence Cyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration). Starter Lock-out Stardard Charger Fault/Missing AC Warning Standard Low Battery/Battery Problem Protection and Battery Condition Indication Standard Low Battery/Battery Problem Protection Standard Low Battery/Battery Problem P	1/2 Load Full Load	70 (Ì.92) [7.28]	104 (2̀.86) [1̇0.82]	140 (3.85) [14.57]
2-Line Plain Text Multi-Lingual LCD Display Simple user interface for ease of operation. Mode Buttons: Auto Automatic Start on Utility failure. 7 day exerciser. Manual Start with starter control, unit stays on. If utility fails, transfer to load takes place. Off Stops unit. Power is removed. Control and charger still operate. Ready to Run/Maintenance Messages Standard Engine Run Hours Indication Standard Programmable start delay between 2-1500 seconds Standard (programmable by dealer only) Utility Voltage Loss/Return to Utility Adjustable From 140-171V/190-216V Future Set Capable Exerciser/Exercise Set Error Warning Standard Run/Alarm/Maintenance Logs 50 Events Each Engine Start Sequence Cyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration). Starter Lock-out Standard Smart Battery Charger Standard Low Battery/Battery Problem Protection and Battery Condition Indication Standard Automatic Voltage Regulation with Over and Under Voltage Protection Standard Under-Frequency//Overload/Stepper Overcurrent Protection Standard Low Battery/Battery Problem Protection Standard Automatic Low Oil Pressure/High Oil Temperature Shutdown Stand	(19-22mm mercury) for LP gas. For Btu content, multiply ft ³ /hr x 2500	generator fuel inlet - 3.5-7" water (LP) or ft³/hr x 1000 (NG). For Mo	column (7-13mm mercury) for nat egajoule content, multiply m³/hr x 9	tural gas, 10-12" water column 93.15 (LP) or m ³ /hr x 37.26
Mode Buttons:AutoAutomatic Start on Utility failure. 7 day exerciser.ManualStart with starter control, unit stays on. If utility fails, transfer to load takes place.OffStops unit. Power is removed. Control and charger still operate.Ready to Run/Maintenance MessagesStandardEngine Run Hours IndicationStandardProgrammable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStandardSmart Battery ChargerStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	CONTROLS			
ManualStart with starter control, unit stays on. If utility fails, transfer to load takes place.OffStops unit. Power is removed. Control and charger still operate.Ready to Run/Maintenance MessagesStandardEngine Run Hours IndicationStandardProgrammable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStandardSmart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	2-Line Plain Text Multi-Lingual LCD Display	Sim	ple user interface for ease of operative	ation.
OffStops unit. Power is removed. Control and charger still operate.Ready to Run/Maintenance MessagesStandardEngine Run Hours IndicationStandardProgrammable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance LogsStandardEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage unil 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Mode Buttons: Auto	Autom	atic Start on Utility failure. 7 day ex	kerciser.
Ready to Run/Maintenance MessagesStandardEngine Run Hours IndicationStandardProgrammable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Manual	Start with starter contr	rol, unit stays on. If utility fails, tran	sfer to load takes place.
Engine Run Hours IndicationStandardProgrammable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Off	Stops unit. Po	ower is removed. Control and charg	jer still operate.
Programmable start delay between 2-1500 secondsStandard (programmable by dealer only)Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard			Standard	
Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Engine Run Hours Indication		Standard	
Utility Voltage Loss/Return to Utility AdjustableFrom 140-171V/190-216VFuture Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Programmable start delay between 2-1500 seconds	St		nly)
Future Set Capable Exerciser/Exercise Set Error WarningStandardRun/Alarm/Maintenance Logs50 Events EachEngine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Utility Voltage Loss/Return to Utility Adjustable			
Engine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard				
Engine Start SequenceCyclic cranking: 16 sec. on, 7 rest (90 sec. maximum duration).Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Run/Alarm/Maintenance Logs		50 Events Each	
Starter Lock-outStarter cannot re-engage until 5 sec. after engine has stopped.Smart Battery ChargerStandardCharger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Engine Start Sequence	Cyclic crankin	g: 16 sec. on, 7 rest (90 sec. maxi	mum duration).
Charger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Starter Lock-out			
Charger Fault/Missing AC WarningStandardLow Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard	Smart Battery Charger		Standard	
Low Battery/Battery Problem Protection and Battery Condition IndicationStandardAutomatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard				
Automatic Voltage Regulation with Over and Under Voltage ProtectionStandardUnder-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard				
Under-Frequency/Overload/Stepper Overcurrent ProtectionStandardSafety Fused/Fuse Problem ProtectionStandardAutomatic Low Oil Pressure/High Oil Temperature ShutdownStandard			Standard	
Safety Fused/Fuse Problem Protection Standard Automatic Low Oil Pressure/High Oil Temperature Shutdown Standard				
Automatic Low Oil Pressure/High Oil Temperature Shutdown Standard				
	•			
High Engine Temperature Shutdown Standard				
Internal Fault/Incorrect Wiring Protection Standard				
-	-			
Common External Fault Capability Standard				
Field Upgradable Firmware Standard Rating definitions - Standby: Applicable for supplying emergency power for the duration of the utility power outage. No overload capability is available for this rating. (All ratings in accordance with BS5514, IS03046 and				

Rating definitions - Standby: Applicable for supplying emergency power for the duration of the utility power outage. No overload capability is available for this rating. (All ratings in accordance with BS5514, ISO3046 and DIN6271). * Maximum wattage and current are subject to and limited by such factors as fuel Btu/megajoule content, ambient temperature, altitude, engine power and condition, etc. Maximum power decreases about 3.5 percent for each 1,000 feet (304.8 meters) above sea level; and also will decrease about 1 percent for each 6° C (10° F) above 16° C (60°F). Sound output ratings from certain points on the generator subject to change based on installation parameters.

AVAILABLE ACCESSORIES

Model #	Product	Description
5819	26R Wet Cell Battery	Every standby generator requires a battery to start the system. Honeywell offers the recommended 26R wet cell battery for use with all air-cooled standby product.
6212	Cold Weather Kit	If the temperature regularly falls below 32°F (0°C), install a cold weather kit to maintain optimal battery and oil temperatures. Kit consists of a battery warmer and oil filter heater with built-in thermostats.
5621	Auxillary Transfer Switch Contact Kit	The auxiliary transfer switch contact kit allows the transfer switch to lock out a single large electrical load you may not need.
6160	Paint Kit	If the generator enclosure is scratched or damaged, it is important to touch-up the paint to protect from future corrosion. The paint kit includes the necessary paint to properly maintain or touch-up a generator enclosure.
6483 (11kW) 6484 (15kW) 6485 (20kW)	Scheduled Mainte- nance Kit	Honeywell's scheduled maintenance kits provide all the hardware necessary to perform complete routine maintenance on a Honeywell automatic standby generator.
6200	PMM Starter Kit	The PMM Starter Kit consists of a 24VAC, field installed transformer that enables the use of the 24VAC Power Management Modules (PMMs) and one PMM. The standard controller (without starter kit) can control two HVAC loads with no additional hardware.
6187	Power Management Module (50 Amps)	Power Management Modules are used in conjunction with the Sync Smart Switch to in- crease its power management capabilities. It gives the Sync Smart Switch additional power management flexibility not found in any other transfer switch.

DIMENSIONS



76.2 mm [3.0 in.]

LEFT SIDE VIEW

Generac Power Systems, Inc.

S45 W29290 Hwy. 59 Waukesha, WI 53187 Tel: 1-855-GEN-INFO honeywellgenerators.com 0198040SBY-D April 2013 © Generac Power Systems, Inc. All rights reserved. Specifications subject to change without notice.

The Honeywell Trademark is used under license from Honeywell International Inc.

Honeywell International Inc. makes no representation or warranties with respect to this product.

